

# eKEY® Fob

## User Instructions

P/N 10103037P1-01 November 2012  
© 2012 UTC Fire & Security. All rights reserved.

### Introduction


The eKEY Fob is a device used to translate the Bluetooth signal from your eKEY enabled smartphone to an infrared signal that can be recognized by an iBox or iBox BT.

The eKEY Fob is compatible with the following smartphones and tablets:

- Android™
- Apple iOS
- BlackBerry®

The eKEY Fob has a power button, an LED light, and a key ring for easy placement on your key chain.

Figure 1. eKEY Fob



### Pairing the eKEY Fob

Before your Apple device and eKEY Fob can communicate, they first need to be paired.

*Note:* The Android and BlackBerry device automatically pair the first time they communicate with the eKEY Fob.

To pair your Apple device and eKEY Fob:

1. On your Apple device, select **Settings**.
2. For an iOS6 device, select **Bluetooth**. For an iOS5 or earlier device, select **General** and then **Bluetooth**.
3. Set Bluetooth to On.
4. Power on the eKEY Fob by pressing and holding the power button until the green light flashes.
5. When you see *Supra-xxxx*, tap to connect.

### Using your eKEY Fob

*Note:* To use the eKEY software you must subscribe to eKEY service through your Association/MLS.

To use your eKEY Fob:

1. Start the iBox operation (Obtain Key, Release Shackle, or Add, Read, or Program iBox) in your eKEY software.
2. Enter your 4-digit PIN.
3. Power on the eKEY Fob by pressing and holding the power button until the green light flashes.
4. Point the eKEY Fob towards the infrared port on the iBox.

*Important:* Hold the eKEY Fob between 6 inches and 2 feet from the iBox for best performance.

The eKEY Fob turns off automatically after an operation and after it has been inactive for 30 seconds.

Table 1. LED descriptions

LED	Description
Green, slow blink	Searching for eKEY
Green, fast blink	Communicating with eKEY
Green, double blink	Searching for iOS device
Red, blink	Low battery



# eKEY® Fob

## User Instructions

P/N 10103037P1-01 November 2012  
© 2012 UTC Fire & Security. All rights reserved.

### Introduction


The eKEY Fob is a device used to translate the Bluetooth signal from your eKEY enabled smartphone to an infrared signal that can be recognized by an iBox or iBox BT.

The eKEY Fob is compatible with the following smartphones and tablets:

- Android™
- Apple iOS
- BlackBerry®

The eKEY Fob has a power button, an LED light, and a key ring for easy placement on your key chain.

Figure 1. eKEY Fob



### Pairing the eKEY Fob

Before your Apple device and eKEY Fob can communicate, they first need to be paired.

*Note:* The Android and BlackBerry device automatically pair the first time they communicate with the eKEY Fob.

To pair your Apple device and eKEY Fob:

1. On your Apple device, select **Settings**.
2. For an iOS6 device, select **Bluetooth**. For an iOS5 or earlier device, select **General** and then **Bluetooth**.
3. Set Bluetooth to On.
4. Power on the eKEY Fob by pressing and holding the power button until the green light flashes.
5. When you see *Supra-xxxx*, tap to connect.

### Using your eKEY Fob

*Note:* To use the eKEY software you must subscribe to eKEY service through your Association/MLS.

To use your eKEY Fob:

1. Start the iBox operation (Obtain Key, Release Shackle, or Add, Read, or Program iBox) in your eKEY software.
2. Enter your 4-digit PIN.
3. Power on the eKEY Fob by pressing and holding the power button until the green light flashes.
4. Point the eKEY Fob towards the infrared port on the iBox.

*Important:* Hold the eKEY Fob between 6 inches and 2 feet from the iBox for best performance.

The eKEY Fob turns off automatically after an operation and after it has been inactive for 30 seconds.

Table 1. LED descriptions

LED	Description
Green, slow blink	Searching for eKEY
Green, fast blink	Communicating with eKEY
Green, double blink	Searching for iOS device
Red, blink	Low battery



## Changing the Batteries



The eKEY Fob comes with two CR2016 lithium coin batteries. You will need to replace the batteries when the red LED flashes. Battery life is subject to usage, conditions, and type of battery used.

To replace the batteries:

1. Insert the tip of a flathead screwdriver into the notch on the side of the eKEY Fob and turn to open the case.
2. Remove the existing batteries.
3. Replace with two new CR2016 batteries with the + polarity facing up on both batteries.
4. Replace the cover and snap to close.

For proper recycling, dispose of all batteries as required by local ordinances or regulations.

Figure 2. Changing the batteries



**Technical Support**  
877.699.6787, 6am to 7pm Pacific time  
[www.supraekey.com](http://www.supraekey.com)

**RoHS**  
COMPLIANT

## Trademark

Supra and eKEY are trademarks of UTC Fire & Security. Android is a trademark of Google Inc. Blackberry is a registered trademark of Research in Motion (RIM). Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG. iPhone is a trademark of Apple Inc., registered in the U.S. and other countries.

“Made for iPhone” means that an electronic accessory has been designed to connect specifically to an iPhone and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

## Warranty

UTC Fire & Security warrants the eKEY Fob for a period of one year after the date of purchase under normal use against defective workmanship and materials (batteries excluded). The warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship.

## FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**2002/96/EC (WEEE directive).** Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information, visit [www.recyclethis.info](http://www.recyclethis.info).

## Changing the Batteries



The eKEY Fob comes with two CR2016 lithium coin batteries. You will need to replace the batteries when the red LED flashes. Battery life is subject to usage, conditions, and type of battery used.

To replace the batteries:

1. Insert the tip of a flathead screwdriver into the notch on the side of the eKEY Fob and turn to open the case.
2. Remove the existing batteries.
3. Replace with two new CR2016 batteries with the + polarity facing up on both batteries.
4. Replace the cover and snap to close.

For proper recycling, dispose of all batteries as required by local ordinances or regulations.

Figure 2. Changing the batteries



**Technical Support**  
877.699.6787, 6am to 7pm Pacific time  
[www.supraekey.com](http://www.supraekey.com)

**RoHS**  
COMPLIANT

## Trademark

Supra and eKEY are trademarks of UTC Fire & Security. Android is a trademark of Google Inc. Blackberry is a registered trademark of Research in Motion (RIM). Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG. iPhone is a trademark of Apple Inc., registered in the U.S. and other countries.

“Made for iPhone” means that an electronic accessory has been designed to connect specifically to an iPhone and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

## Warranty

UTC Fire & Security warrants the eKEY Fob for a period of one year after the date of purchase under normal use against defective workmanship and materials (batteries excluded). The warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship.

## FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**2002/96/EC (WEEE directive).** Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information, visit [www.recyclethis.info](http://www.recyclethis.info).